

I want a hassle-free system that's quick and easy to apply

The new 3M™ Scotchkote™ Liquid Roofing system can be applied by brush or roller to variety of substrates.* Simply apply 3M™ 1900 Duct Tape to any exposed gaps or edges, apply 3M™ Scotchkote™ Roof Detailing Compound SDR 655 by brush and allow to cure.

The area is then ready for application of the 3M™ Scotchkote™ Roofing Urethane Roof Coating SD 650. Two coats are recommended to give a total coverage of 1.5 litres per m².

The low solvent formulation results in a vastly reduced odour application, with minimal disruption to you and your client.

*primer may be required



Infrastructure Protection Division 3M United Kingdom plc

23 Standard Way Business Park
Northallerton
North Yorkshire DL6 2XA
Telephone: +44 (0)845 6028083
Facsimile: +44 (0)1609 783762 (Orders)
+44 (0)1609 788707 (Sales)
Email: roofing.cpp.uk@mmm.com
Website: www.3M.co.uk/scotchkote

Infrastructure Protection Division 3M Ireland Limited

The Iveagh Building
The Park, Carrickmines
DUBLIN 18
Telephone: +353 (0) 1 2803555
Facsimile: +353 (0) 1 2803509

Website: www.3M.ie

Summary

- ✓ No reinforcing mat or fleece required
- ✓ Cure time of 2 hours at 20°C
- ✓ Low odour
- ✓ 25 year Life to First Maintenance
- ✓ Fire Resistance Rating AA to BS476 Part 3:1958

For further information on this revolutionary new roofing system please get in touch with us on **0845 6028083** or visit us at www.3M.co.uk/samedayroof

Please recycle. Printed in the United Kingdom.
© 3M 2012. All rights reserved.



3M™ Scotchkote™ Roofing Liquid Membrane Systems



The time saving
solution
one day, mat free liquid roof
installation



“I need to be sure the product will do the job”

“Time is money”

“My key driver is cost”



The new 3M™ Scotchkote™ Liquid Roofing system has been developed by talking to roofing contractors to understand what’s important to them.

Time is money

That’s why we have developed a liquid waterproof roofing system that we believe is second to none when it comes to installation time. Our system is so durable that there is **no need for reinforcing mats or materials**, saving huge amounts of time and effort typically spent on detailing.

Add to this a cure-time of approximately 2 hours*, and 3M™ Scotchkote™ Urethane Roof Coating SD 650 offers contractors the ability to reduce labour time by between 33-80%. Not to mention the additional costs associated with scaffolding hire, the use of skilled labour and materials.

Now an installation in 1 day is a real possibility!

“Reduce the smell”

“I want a hassle-free system that’s quick and easy to apply”

Example Project – 100m²

	Existing 3M 25 Year System	New 3M 25 Year System
Site Preparation (Power wash etc)	0.5 days	0.5 days
Primer (if required)	1 day	1 day
Detailing Work	<ul style="list-style-type: none"> - Tape joints - Lay reinforcement on joints - Apply stripe coat of embedment 1 day	<ul style="list-style-type: none"> - Tape joints - Brush over reinforcing liquid - Cure (2 hours) 0.5 days
Embedment coat	<ul style="list-style-type: none"> - Apply embedment coat - Lay reinforcing mat over complete deck - Back roller embedment coat - Cure (8 hours/overnight) 1 day	<ul style="list-style-type: none"> - Apply - Cure (2 hours) 0.5 days
Top Coat 2	<ul style="list-style-type: none"> - Apply - Cure (8 hours/overnight) 1 day	<ul style="list-style-type: none"> - Apply - Cure (2 hours) 0.5 days
TOTAL	4.5 days	3 days

*at 20°C temperature

I need to be sure product will do the job

The system has been stringently tested versus our existing 25 year system (3M™ Scotchkote™ Poly-Tech EC 661/UV 662) in all the tests required for European Technical Approval (ETAG-005) certification such as accelerated weathering and fire testing. In all cases, the new product performed better than or as well as our existing certified product, meaning 3M has the utmost confidence in offering a Life to First Maintenance of 25 years.

The superior mechanical properties result in a system that does not require any form of ancillary reinforcing (mat or fleece) on the complete deck. Simply use 3M™ Scotchkote™ Roof Detailing Compound SDR 655, our new revolutionary reinforced liquid system for detail areas.

And when tested in the field, contractors have been extremely impressed by the ease and speed of application.

